

NSWC TR 83-382

(12)

AD-A143 635

PROPERTIES OF PRINCIPLE TL DOSIMETERS

BY V. K. MATHUR

RESEARCH AND TECHNOLOGY DEPARTMENT

OCTOBER 1983

Approved for public release, distribution unlimited.

DTIC
ELECTE
JUL 31 1984
B

DTIC FILE COPY



NAVAL SURFACE WEAPONS CENTER

Dahlgren, Virginia 22448 • Silver Spring, Maryland 20910

Reproduced From
Best Available Copy

20000803011

84 07 31 014

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER NSWC TR 83-382	2. GOVT ACCESSION NO. DA 1143 635	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) PROPERTIES OF PRINCIPAL TL DOSIMETERS	5. TYPE OF REPORT & PERIOD Final	
7. AUTHOR(s) V. K. MATHUR	6. PERFORMING ORG. REPORT NUMBER	
9. PERFORMING ORGANIZATION NAME AND ADDRESS Naval Surface Weapons Center (Code R41) White Oak, Silver Spring, Maryland 20910	8. CONTRACT OR GRANT NUMBER	
11. CONTROLLING OFFICE NAME AND ADDRESS	10. PROGRAM ELEMENT PROJECT TASK AREA & WORK UNIT NUMBERS AA 1741804 DM&N 4R41GA	
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)	12. REPORT DATE October 1983	
	13. NUMBER OF PAGES 36	
	15. SECURITY CLASS. (of this report) UNCLASSIFIED	
	15a. DECLASSIFICATION/DOWNGRADING SCHEDULE	
16. DISTRIBUTION STATEMENT (of this Report) Approved for public release, distribution unlimited.		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		
18. SUPPLEMENTARY NOTES		
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) Dosimeter, Thermoluminescence, Radiation Measurement, Phosphors		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) Of the various techniques that can be used for personnel dosimetry, thermoluminescence dosimetry has emerged as a superior technique due to its manifold advantages over other methods of dose estimation. This has led to the formulation of desired characteristics of a TL dosimeter. Various phosphors have been therefore investigated regarding their suitability for dosimetry. A brief description of important TL materials and their properties is documented in this report.		

DD FORM 1 JAN 73, 1473

EDITION OF 1 NOV 65 IS OBSOLETE
S/N 0102-LF-014-6601

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

FOREWORD

Of the various techniques that can be used for personnel dosimetry, thermoluminescence dosimetry has emerged as a superior technique due to its manifold advantages over other methods of dose estimation. This has lead to the formulation of desired characteristics of a TL dosimeter. Various phosphors have been therefore, investigated regarding their suitability for dosimetry. A brief description of important TL materials and their properties is documented in this report.

Approved by:

IRA M. Blatstein
 IRA M. BLATSTEIN, Head
 Radiation Division

DTIC
ELECTE
 JUL 31 1984
B

Accession For	
NTIC	<input checked="" type="checkbox"/>
DTIC	<input type="checkbox"/>
Unprocessed	<input type="checkbox"/>
Justified	<input type="checkbox"/>
PER JS	
By	
Distribution	
Availability	
Dist	Special
A-1	

CONTENTS

<u>Chapter</u>		<u>Page</u>
1	INTRODUCTION	1
2	DOSE LINEARITY	3
3	FADING	5
4	ANNEALING	9
5	DOSE RATE DEPENDENCE	11
6	SPURIOUS THERMOLUMINESCENCE	13
7	CHARACTERISTICS OF TL DOSIMETERS	15
	LITHIUM FLUORIDE	15
	LITHIUM BORATE	16
	CALCIUM FLUORIDE	17
	CALCIUM SULPHATE	18
	ALUMINUM OXIDE (AL ₂ O ₃)	19
	BERYLLIUM OXIDE	19
	MAGNESIUM BORATE	19
8	PHOTON RESPONSE	21
9	B-RAY RESPONSE	23
10	NEUTRON RESPONSE	25
11	LASER HEATING	27
	REFERENCES	35

ILLUSTRATIONS

<u>Figure</u>		<u>Page</u>
1	GLow CURVES OF LiF TLD 100 (HARSHAW) AND LiF PTL 710 (DESMARQUEST)	29
2	GLow CURVES OF $\text{Li}_2\text{B}_4\text{O}_7:\text{Mn}$ AT 3.4, 8.6, 27.3, 69.2 AND 960 MIN, RESPECTIVELY AFTER IRRADIATION	30
3	GLow CURVE OF $\text{CaF}_2:\text{Mn}$	31
4	GLow CURVE OF $\text{CaF}_2:\text{Dy}$	32
5	GLow CURVE OF $\text{CaSO}_4:\text{Dy}$ AND $\text{CaSO}_4:\text{Tm}$	33
6	GLow CURVE OF Al_2O_3	34

TABLES

<u>Table</u>		<u>Page</u>
1	LINEARITY RANGES	3
2	GLow PEAK TEMPERATURES AND HALF-LIFE/FADING	5
3	ANNEALING PROCEDURES	9
4	PEAK TEMPERATURE AND HALF-LIFE OF CORRESPONDING TRAP LEVEL	16
5	SLOW NEUTRON SENSITIVITY	25

CHAPTER 1

INTRODUCTION

The use of nuclear energy for ship propulsion and the development of nuclear weapons has generated a demand for personal dosimetry of the individual worker on a routine basis. The worker may be exposed to the hazard of γ -rays, β -rays and neutrons. Of these three, γ -rays are very penetrative and plentiful. However, the determination of the radiation exposure for γ -rays is a straight forward and accurate procedure. The determination of the dose due to β -rays is difficult because of their low penetration and energy dependence. It is very hard to determine the doses of fast neutrons accurately due to their non-ionizing nature.

Of the various techniques that can be used to estimate the doses of hazardous radiation, thermoluminescence dosimetry (TLD) emerged as the preferred means because of convenience of batch evaluation, reusability, large detection range, linearity and cost effectiveness. More than 3000 minerals exhibit thermoluminescence but only a handful of them have the desired characteristics for a dosimeter, of which only half a dozen are established as good dosimeters. The most commonly used TL phosphors for dosimetry are: (1) Lithium Fluoride (LiF), (2) Lithium Borate ($\text{Li}_2\text{B}_4\text{O}_7$), (3) Calcium Fluoride (CaF_2), (4) Calcium Sulphate (CaSO_4), (5) Aluminum Oxide (Al_2O_3), (6) Beryllium Oxide (BeO), and (7) Magnesium Borate (MgB_4O_7).

CHAPTER 2

DOSE LINEARITY

To be a good dosimeter, a TL material must have a linear dose-TL signal relationship. For this circumstance, the thermoluminescence signal Q_{TL} and absorbed dose D are related as follows

$$Q_{TL} = \alpha Y_{TL} D \quad (1)$$

where α is a constant of proportionality and Y_{TL} is energy emitted as light per unit mass of the phosphor per unit absorbed dose. In the linear region Y_{TL} is constant.

Table 1 gives the dose ranges within which detectors show a linear behavior. In general, the deviation from linearity is due to the presence of supra-linearity. The origin of this phenomenon is not completely understood.

TABLE 1. LINEARITY RANGES

TL Material	Linearity range for ^{60}Co gamma rays (order of magnitude) (rad)
LiF:Mg,Ti	$10^{-2} - 10^2$
$\text{Li}_2\text{B}_4\text{O}_7:\text{Mn}$	$10^{-2} - 10^2$
$\text{CaF}_2:\text{Mn}$	$10^{-4} - 10^3$
$\text{CaF}_2:\text{Dy}$	$10^{-5} - 10^3$
BeO	$10^{-2} - 10^2$
$\text{CaSO}_4:\text{Dy}$	$10^{-4} - 10^3$
$\text{CaSO}_4:\text{Tm}$	$10^{-4} - 10^2$
Al_2O_3	No linear characteristics

It may be remarked that in the supralinearity region, the TL detector maintains the new sensitivity even after the dose readout. To restore its initial sensitivity a complete annealing cycle is needed. Beyond the supralinearity range "saturation" sets in due to the decrease in the number of available traps. This determines the upper dose limit for each detector, which is usually estimated to be 20% below the saturation value.

Lower dose limit or detection threshold is defined as the smallest dose that can be distinguished significantly from a zero dose and is taken as three times the standard deviation of the zero dose reading expressed in units of absorbed dose.

CHAPTER 3

FADING

The dose stored in a phosphor may slowly be removed because of the thermal release of electrons or holes from their traps. This is called "Fading." A good TL dosimeter should not exhibit significant fading over the time the dosimeter is stored before dose read out.

The release of electrons and holes from their traps and consequently their recombination is a statistical phenomenon. The probability of detrapping is a function of temperature, which is given by

$$P = S \exp (- E/kT)$$

Where S = vibrational factor characteristic of the trap, E = activation energy, k = Boltzmann's constant, and T = absolute temperature. The half-life of the phenomenon is given by

$$\tau = 0.693 P^{-1} \quad (2)$$

Table 2 gives the temperature of the different peaks and information on the stability of the carriers in the corresponding traps at 20°C for some phosphors.

TABLE 2. GLOW PEAK TEMPERATURES AND HALF-LIFE/FADING

TL Material	Peak Number	Emission Temp (°C)	Half-life/Fading
LiF:Mg	I	70	5 min
	II	130	10 hr
	III	170	0.5 yr
	IV	200	7 yr
	V	225	80 yr
CaF ₂ :Mn	I	260	1% per day
CaF ₂ :Dy	I	120	
II	140		

TABLE 2 (cont.)

TL Material	Peak Number	Emission Temp (°C)	Half-life Fading
BeO	III	200	25% per month
	IV	240	
	I	70	0% per 5 months
	II	160	
Li ₂ B ₄ O ₇ :Mn	III	180	
	IV	220	
	I	50	10% per 2 months
	II	90	
CaSO ₄ :Dy	III	200	
	IV	220	
	I	80	7% per 6 months
	II	120	
Al ₂ O ₃	III	220	
	IV	260	
	I	103	1 hr
	II	123	140 hrs
	III	164	115 d
	IV	236	1.8 x 10 ⁷ yr

It is easy to conclude from the table above that shallow traps have smaller half lives and will fade more rapidly than deep ones due to a larger transition probability. Fading can lead to large errors in dose assessment. In some instances, the shallow traps which are responsible for fading are emptied intentionally by post-irradiation anneal in a separate oven or in the reader as a part of the readout process. In addition to thermal fading, any exposure to artificial light or sunlight can modify the actual dose due to the following phenomena:

- spurious dose due to the creation of electron-hole pairs by absorption of near U-V light.
- the loss of latent dose information due to optical fading arising through optical stimulation of trapped electrons.

NSWC TR 83-382

However, the effect of light exposure on detectors can be easily avoided by keeping them in a light tight environment.

CHAPTER 4

ANNEALING

Each TL material used in dosimetry requires pre-dose annealing for restoring its initial conditions after an irradiation. Annealing results in emptying the traps of the phosphor completely after the irradiation and readout cycle and it also stabilizes the electron traps in order to obtain, within narrow limits, the same glow curves even after repeated irradiations and thermal treatments. Annealing is very critical in the case of LiF, because if the procedure is not always identical, one can obtain significantly different glow curves from repeated irradiations to the same exposure.

In Table 3 are summarized the annealing procedures for several TL materials used in practice.

TABLE 3. ANNEALING PROCEDURES

TL MATERIAL	Annealing Procedures	Pre-read Annealing
LiF(TLD 100)	1 h at 400°C+24 h at 80°C (or 2 h at 100°C)	10 min at 100°C
Li ₂ B ₄ O ₇ :Mn	15 min at 300°C	10 min at 100°C
BeO	15 min at 600°C	
CaF ₂ :Dy (TLD) 200)	1 h at 400°C	
CaF ₂ :Mn	1 h AT 400°C	
LiF (PTL 700)	240-250°C in the reader	Performed in the reader

A TL material which is a candidate for dosimetric applications should not go through any physicochemical changes during the repeated annealing and exposures. This ensures that the glow curve, TL yield and non-radiation induced light emission must not change during storage, irradiation and dose readout. Stability of a phosphor is measured as reproducibility by calculating the standard deviation of a repeated set of measurements under the same exposure and reading conditions.

CHAPTER 5
DOSE RATE DEPENDENCE

LiF, $\text{Li}_2\text{B}_4\text{O}_7\text{:Mn}$ and BeO were studied for their dose rate dependence by exposing these detectors to very short pulses ($\approx 10^{-9}$ s) of high intensity x-rays. It was observed that:

1. the response of LiF is not modified up to an exposure of $1.5 \times 10^{11} \text{ Rs}^{-1}$;
2. the response of BeO is not modified up to $5 \times 10^{11} \text{ Rs}^{-1}$;
3. the response of $\text{Li}_2\text{B}_4\text{O}_7$ is independent of dose rate up to 10^{12} Rs^{-1} .

The independence of TL response to dose rate points out the possibility of their use near installation delivering photons in very short pulses.

CHAPTER 6

SPURIOUS THERMOLUMINESCENCE

A spurious signal is sometimes obtained due to tribo-thermoluminescence (TTL), which increases the detection threshold and the error in the dose assessment. This phenomenon is eliminated when the detector is heated in an inert atmosphere of argon or nitrogen. It is negligible in the dose measurement at therapy levels (doses of the order of several hundred rads) but can be significant for personnel dosimetry. $\text{CaF}_2:\text{Mn}$ exhibits a TTL peak around 360°C in air. Argon ambient shifts this peak to 460°C , although it does not suppress it. The TTL signal in air is no more than one fifth the γ -ray response in $\text{CaF}_2:\text{Mn}$.

CHAPTER 7

CHARACTERISTICS OF TL DOSEMETERS

We describe below in brief details the individual characteristics of various TL phosphors used in dosimeters.

LITHIUM FLUORIDE

LiF is the most important TL material used for dosimetry. Due to its approximately tissue equivalent response, LiF has found wide application in personnel dosimetry and health physics. However, in practice it has a comparatively poor TL yield and complex glow peak structure. Thermoluminescence of LiF is attributed to the presence of Mg and Ti impurities. The commercial products marketed by Harshaw are termed as TLD 100, TLD 600 and TLD 700 according to their preparation from natural lithium or lithium enriched with ^6Li or ^7Li . A similar quality LiF, stabilized with Sodium was studied in France and marketed by Desmarquest under the name PTL 710, 716 and 717. These products, unlike Harshaw products, do not require systematic regeneration before each usage.

The glow curve of LiF consists essentially of six peaks as shown in Figure 1. These peaks are numbered consecutively in ascending order of their peak temperature. The peak V, which occurs at 225°C is normally used for dosimetric purposes. Low temperature peaks I, II and III are relatively unstable and must be suppressed by a thermal regeneration process. For sodium stabilized LiF, annealing is necessary only for heavily irradiated samples. Table 4 shows the peak temperature and the half-life of corresponding trap levels.

TABLE 4. PEAK TEMPERATURE AND HALF-LIFE OF CORRESPONDING TRAP LEVEL

Phosphor	Peak No.	Peak Temperature (°C)	Half-Life
LiF TLD	I	65	5 min
	II		10 h
	III	120	0.5 yr
	IV	160	7 yr
	V	195	80 yr
	VI	210	not measured
LiF PTL	I	275	20 min
	II	80	80 hr
	V	130	1.3×10^7 yr
	VI	220	not measured
		280	

For both LiF TLD and LiF PTL the maximum of the emission occurs at 400 nm. The emission is identical for all traps. The intrinsic TL efficiency (the ratio of energy emitted in the form of light per unit of phosphor mass and absorbed dose) is 0.04, which is low compared to other dosimeters. The effective atomic number of LiF is close to that of tissue ($Z_{eff}(\text{LiF}) = 8.14$, $Z_{eff}(\text{tissue}) = 7.4$). Therefore, its response varies only slightly with photon energy: it varies by about 30% between 3.0 keV and 1.2 MeV.

LITHIUM BORATE

Lithium Borate has been activated by Mn as well as Cu to synthesize TL dosimeters. A mixture of 32.5g of lithium carbonate and 108.96g of boric acid is added to a 5 ml aqueous solution of 75 mg of $\text{MnCl}_2 \cdot 4\text{H}_2\text{O}$ and subsequently heated at 100°C for 12 h. The product is placed in a platinum crucible, heated up to 950°C and then rapidly cooled. The crystalline mass is then ground and graded between 75 and 175 μm . The glow curve of $\text{Li}_2\text{B}_4\text{O}_7:\text{Mn}$ is shown in Figure 2. It can be divided in two distinct parts:

- (1) one part consists of unstable peaks between 50°C and 90°C
- (2) the second part consists of a double peak, the first of which appears at 200°C at low doses and the second of which appears at 220°C for doses in excess of 50 rad. With high LET radiation another peak occurs at 350°C.

The double peak, used for dosimetry, fades 10 and 37% in 2 and 13 months at ambient temperature. The addition of SiO_2 (0.5%) to the phosphor reduces the influence of humidity on lithium borate which is very hygroscopic. This phosphor can be used without regeneration. For zeroing the phosphor after high doses it is sufficient to reheat the material at 300°C for 35 min.

The maximum wavelength of emission from $\text{Li}_2\text{B}_4\text{O}_7:\text{Mn}$ is about 600 nm. This limits the sensitivity of this phosphor to 1/2 of that of LiF with an S20 photocathode in spite of the fact that the intrinsic sensitivity of $\text{Li}_2\text{B}_4\text{O}_7:\text{Mn}$ is a factor of 1.83 higher than that of LiF . Doping $\text{Li}_2\text{B}_4\text{O}_7$ with Cu results in two TL peaks at about 120°C and a dominant, stable peak at 205°C. The sensitivity of this phosphor is 20 times higher than $\text{Li}_2\text{B}_4\text{O}_7:\text{Mn}$. One of the factors contributing to this relatively high sensitivity is the favorable spectral location of the TL emission which peaks at 368 nm.

CALCIUM FLUORIDE

CaF_2 is considerably more sensitive than Lithium Fluoride; the minimum detectable limit is about 10 times less and it has a larger linear dose response range but it is not tissue equivalent ($Z_{\text{eff}} = 16.57$). Natural CaF_2 has a favorable emission at 375 nm, although it exhibits different dosimetric characteristics depending upon the origin of the sample.

Mn doped (3%) CaF_2 is synthesized by co-precipitation of CaF_2 and MnF_2 from a solution of CaCl_2 and MnCl_2 in ammonium fluoride. The precipitate is dried and heated in an oven at 1200°C under neutral ambient. The product is then crushed and graded and finally pressed or sintered. The TL glow curve consists of a main peak at 260°C as shown in Figure 3. This peak is a convolution of several overlapping peaks which results from several trap levels located very close to each other. Due to the presence of high temperature peaks, which cause evaluation difficulties when the phosphor is exposed to high doses, the sample must be reheated after a high dose to empty the deeper trap levels before being used for low-dose measurements. CaF_2 fades at the rate of 1% per day. The light emission at 500 nm is characteristic of Mn. The intrinsic sensitivity of $\text{CaF}_2:\text{Mn}$ is 0.44.

$\text{CaF}_2:\text{Mn}$ is the mainstay of Navy's dosimetric program. It has great merit in stability, clean dosimetric peak and simplicity of operation. However, this phosphor exhibits an anomalous fading. This fading is much more rapid initially than expected from its high temperature glow peak. Schulman attributed this phenomenon to the shifting of the glow peak at high heating rates to the temperature where thermal quenching takes place. Anomalous fading has been observed in a number of phosphors since then and is now generally attributed to the tunnelings of electrons from the traps to the nearest luminescent center non-radiatively.

Recently, single crystals of $\text{CaF}_2:\text{Mn}$ obtained from Optovac and Navy dosimeters supplied by Harshaw Chemicals were studied at the Center. It was interesting to observe that the glow curve spectrum in these two products was not identical. Optovac samples exhibited an additional glow peak in 50-80°C range.

Dysprosium doped CaF_2 is more sensitive than $\text{CaF}_2:\text{Mn}$. The glow curve of $\text{CaF}_2:\text{Dy}$ consists of six peaks which are difficult to separate (see Figure 4). This is true for the unstable peaks at 120°C and 140°C as well as for the stable peaks at 200°C and 250°C. Two higher temperature peaks appear at 340°C and 400°C. It is not a stable material and exhibits strong fading. A thermal treatment of 10 min at 80°C reduces the fading from 25 to 13% per month.

The TL emission of $\text{CaF}_2:\text{Dy}$ exhibits three maxima which occur at 460, 483 and 576 nm. The presence of the numerous peaks in the glow curve results in a complicated dose response curve. Therefore, measurements based on light integration only make sense. It is used mostly for the measurement of low doses but is being replaced by calcium sulphate activated with dysprosium, which is more stable.

CALCIUM SULPHATE

CaSO_4 is one of the most sensitive TLD products used in dosimetry. $\text{CaSO}_4:\text{Mn}$ has been used for detection of doses as low as 20 μrad but exhibits very strong fading as its TL peak occurs at 90°C. $\text{CaSO}_4:\text{Dy}$ and $\text{CaSO}_4:\text{Tm}$ are the most interesting phosphors in CaSO_4 series, since their response is considerably more stable.

To synthesize these phosphors, 75 mg of powdered dysprosium oxide (Dy_2O_3) or 80 mg thulium oxide (Tm_2O_3) are dissolved in 250 c.c. of concentrated sulphuric acid. The solution is heated in a crucible up to 250°C and 34.4 g of calcium sulphate ($\text{CaSO}_4 \cdot 2\text{H}_2\text{O}$) is added. The solution is then evaporated at 300°C until CaSO_4 crystallizes. The crystals are pulverized and graded to 75-200 μm . This powder is heated at 750°C for 2 h in an aluminum oxide crucible in air and subsequently heat treated at 400°C for 15 min.

The glow curve of $\text{CaSO}_4:\text{Dy}/\text{Tm}$ exhibit two low temperature peaks at 80°C and 120°C. The dosimetric peak occurs at 220°C (see Figure 5). A high temperature peak occurs at 250°C for doses in excess of several thousand rads for $\text{CaSO}_4:\text{Dy}$. Low temperature peaks are eliminated by post-dose annealing at 100°C. Both these phosphors are light sensitive. The luminescence spectrum of $\text{CaSO}_4:\text{Dy}$ has two emission peaks, one at 478 nm and another at 571 nm. $\text{CaSO}_4:\text{Tm}$ emits a main peak at 452 nm and less important peaks at 360, 470 and 520 nm.

$\text{CaSO}_4:\text{Dy}$ and $\text{CaSO}_4:\text{Tm}$ are both more sensitive to photon radiation than LiF . The minimum detection limit is as low as 0.1 mrad. The tribothermoluminescence noise is negligible. The effective atomic number of $\text{CaSO}_4:\text{Dy}/\text{Tm}$ is 15.6. The response to 30 keV photon radiation is 11 times greater than that obtained with ^{60}Co radiation.

ALUMINUM OXIDE (Al_2O_3)

Aluminum oxide is low cost material since it has other industrial applications. It exhibits four peaks at 103°C, 123°C, 164°C and 236°C. The first three peaks are merged as shown in Figure 6. The dosimetric peak (IV) appears with bakes at temperatures greater than 1000°C where Alumina is completely dehydrated. This peak is attributed to sodium impurity. The trapping state corresponding to peak IV is very stable (half-life at 20°C = 1.8×10^7 yr). The heating cycle during the readout process does not affect the glow curves. It can be regenerated by annealing at 500°C for 1 h. Al_2O_3 should be stored away from light after irradiation.

Al_2O_3 emits strongly in the 650 nm region and weakly between 390 and 550 nm. It is the latter emission which is detected with an ordinary commercial TL reader.

Using peak IV only, a minimum dose of 100 mrad can be detected with N_2 flushing. Without N_2 flushing triboluminescence results in an increase of the lower detection threshold to about 10 rad. Al_2O_3 is less photon energy dependent than CaSO_4 .

BERYLLIUM OXIDE

This phosphor is commercially available in microcrystalline powder form. It is extremely toxic when dispersed in air as a fine powder. Sintered pellets are also available which present no danger as long as abrasion of the surface and therefore production of powder and dust is avoided. The inclusion of sodium increases the sensitivity of the pellets. A typical product exhibits two stable neighboring peaks at 180°C and 220°C respectively. The second peak appears at the relatively high doses and becomes preponderant about 1000 rad. Its TL emission extends into the ultraviolet.

By using a photomultiplier with quartz window, the sensitivity of BeO equals that of LiF. Dosimeters sensitised with sodium are very sensitive and allow the measurement of doses down to 1 mrad. This material is highly light sensitive and exposure to fluorescent light accelerates fading by optical stimulation. It is a good tissue equivalent ($Z = 7.13$) material. It is 60% more sensitive to 10-50 keV photon radiation compared with ^{60}Co γ-rays. Unlike LiF and $\text{Li}_2\text{B}_4\text{O}_7:\text{Mn}$, BeO exhibits an increased response with increasing LET. This property of BeO may be utilized for identifying the type of incident radiation.

MAGNESIUM BORATE

Magnesium Borate dosimeters doped with Dysprosium or Thulium have been recently reported. A little amount of yttrium is used as a sensitiser of the TL emission. The material is used in the form of sintered dosimeters. $\text{MgB}_4\text{O}_7:\text{Dy}$ emits a green yellow band, while $\text{MgB}_4\text{O}_7:\text{Tm}$ emits a blue band. The emission of the Dy activated dosimeter is unaffected by the presence of a co-activator, however a co-activator changes the emission in Tm activated material into a green yellow light. These TL dosimeters are seven times more sensitive than LiF

TLD 100, while its effective atomic number is similar to that of LiF. This dosimeter is not light sensitive or hygroscopic and can detect exposure of 1 mrad. It does not require annealing before irradiation or after read-out. It fades less than 10% during first 60 d after irradiation when an appropriate post irradiation annealing is applied.

CHAPTER 8

PHOTON RESPONSE

For any practical dosimetric application, the knowledge of energy response is important. The energy response is a measure of the energy absorbed in the TL material used in comparison to the energy absorbed in a material taken as the reference, when irradiated at the same exposure. Normal reference materials are air and tissue. The energy response can easily be calculated as the ratio between the mass energy absorption coefficients of the detector and air respectively in the energy range up to 3 MeV.

If $S(E)$ is the energy response one has

$$S(E) = (\mu_{en}/\rho)_d / (\mu_{en}/\rho)_{air}$$

where d stands for detector.

Since $(\mu_{en}/\rho)_d$ commonly refers to a compound or a mixture of different elements, the additivity rule must be used to calculate it at every energy value

$$(\mu_{en}/\rho)_d = (\mu_{en}/\rho)_1 w_1 + (\mu_{en}/\rho)_2 w_2 + \dots + (\mu_{en}/\rho)_i w_i + \dots$$

where $(\mu_{en}/\rho)_i$ is the mass energy absorption coefficient of the i^{th} element and w_i is its fraction by weight. For dosimetric purposes, a material with a constant energy response over the energy range of interest is desirable. This can be achieved by choosing materials with a low effective atomic number Z .

CHAPTER 9
β-RAY RESPONSE

TL materials are sensitive to β-rays. However, due to the large dimensions of the grains of a phosphor powder and/or large thickness of a compacted detector, the response of the detector decreases sharply in the low energy range of β-rays. Laser heating of thin film detectors is being studied presently to detect low energy β-rays.

CHAPTER 10

NEUTRON RESPONSE

TL dosimeters are now being increasingly used to monitor neutron doses. There is a need to monitor neutron doses in mixed n, γ fields. The sensitivity to neutrons of TL phosphors depends on their thickness, isotropic composition, irradiation condition and, to some extent, on the activators. LiF and $\text{Li}_2\text{B}_4\text{O}_7$ can be synthesized with different abundances of ^6Li and ^{10}B , thus increasing markedly their slow neutron sensitivity. Table 5 shows the response of a number of TL materials to a fluence of 10^{10} thermal neutrons cm^{-2} in terms of an equivalent exposure to ^{60}Co gamma rays.

TABLE 5. SLOW NEUTRON SENSITIVITY

Material	Response(10^{10} cm^{-2})/Response(R of ^{60}Co gamma ray)
LiF (TLD 100)	350
$\text{Li}_2\text{B}_4\text{O}_7:\text{Mn}$	310
LiF (TLD 600)	1930
LiF (TLD 700)	1.5
$\text{CaF}_2:\text{Mn}$	0.6
$\text{CaSO}_4:\text{Dy}$	0.5
BeO	0.3

The response of TL materials to fast neutrons is rather low. Various techniques have been tried to increase the neutron response of the main dosimetry peaks such as (i) using a hydrogenous material to provide recoil protons, (ii) using a foil of fissionable material and detecting the fragments and (iii) using a moderator to thermalise the neutrons. $\text{CaSO}_4:\text{Dy}$ in conjunction with proton radiator has proven to be a good tool for the detection of fast neutrons by using laser heating technique.

PAGES 27/28
ARE
MISSING
IN
ORIGINAL
DOCUMENT




FIGURE 1. GLOW CURVES OF LiF TLD 100 (HARSHAW) AND LiF PTL 710 (DESMARQUEST)




FIGURE 2. GLOW CURVES OF $\text{Li}_2\text{B}_4\text{O}_7:\text{Mn}$ AT 3.4, 8.6, 27.3, 69.2 AND 960 MIN, RESPECTIVELY AFTER IRRADIATION




FIGURE 3. GLOW CURVE OF $\text{CaF}_2:\text{Mn}$




FIGURE 4. GLOW CURVE OF $\text{CaF}_2:\text{Dy}$




FIGURE 5. GLOW CURVE OF $\text{CaSO}_4:\text{Dy}$ AND $\text{CaSO}_4:\text{Tm}$




FIGURE 6. GLOW CURVE OF Al_2O_3

REFERENCES

1. 1975 Technical Recommendations for the Use of Thermoluminescence for Dosimetry in Individual Monitoring for Photons and Electrons from External Sources, Commission of the European Communities Doc. EUR 5358.
2. G. Portal, Commissariat à l'Energie Atomique Rep. No. R-4697, France, 1975.
3. "Applied Thermoluminescence Dosimetry," Ed. M. Oberhofer and A. Scharmann (Adam Hilger Ltd, Bristol, 1981).
4. Proceedings of 1st International Conference on Luminescence Dosimetry, Stanford University, June 1965, USAEC Div. Tech. Int. AEC8.
5. Proceedings of 2nd International Conference on Luminescence Dosimetry (U), Gatlinburg, Tenn., Sep 1968, USAEC Rpt 680920.
6. Proceedings of 3rd International Conference on Luminescence Dosimetry, Riso, Denmark, Oct 1971, Danish AEC Rep. 249.
7. Proceedings of 4th International Conference on Luminescence Dosimetry, Krakow, Poland, Aug 1974, Inst. Nucl. Phys.
8. Proceedings of 5th International Conference on Luminescence Dosimetry, Sao Paulo FRG, Oct 1977, Physikalisches Institut, Giessen.
9. Proceedings of 6th International Conference on Solid State Dosimetry, Toulouse, France, Apr 1980, Nucl. Instrum. Meth., 175, No. 1.

10. "Thermoluminescence Fast Neutron Dosimetry by Laser Heating,"
V. K. Mathur, M. D. Brown, and P. Braunlich, Proceedings of 7th
International Conference on Solid State Dosimetry, Ottawa, Canada,
27-30 Sep 1983.
11. "Anomalous Fading of $\text{CaF}_2\text{:Mn}$ TL Dosimeters," J. H. Schulman,
R. J. Ginther, S. G. Gorbics, A. E. Nash, E. J. West, and F. H. Attix,
Int. J. Appl. Rad. and Isotopes, 20, 1969, p. 523.
12. "Temperature Dependence of the Fluorescence Spectra of Single Crystal
 $\text{CaF}_2\text{:Mn}$," R. J. Abbundi, D. W. Cooke, V. K. Mathur, G. A. Royce and
M. D. Brown, Proceedings of 7th International Conference on Solid State
Dosimetry, Ottawa, Canada, 27-30 Sep 1983.
13. "Laser Heating in Thermoluminescence Dosimetry," J. Gasiot, P. Braunlich
and J. P. Fillard, J. Appl. Phys., 53, 1982, p. 5200.

DISTRIBUTION

Copies

Naval Electronics Systems Command
 Attn: Code 8153 - James C. Irvine 1
 Jake Kimbrough 1
 Mike Schaeffer 1
 Hank Becker 1
 CDR Marlene Elkins 1
 Washington, D. C. 20362

Naval Sea Systems Command
 Attn: Code 08R - Dennis Rushworth 1
 Washington, D. C. 20362

Defense Technical Information Center
 Cameron Station
 Alexandria, VA 22314 12

Internal Distribution:

R41 (Hesse) 1
 (Riel) 1
 (Brown) 1
 (Rhodes) 1
 (Sam) 1
 (Schulte) 1
 (White) 1
 (Donovan) 1
 (Stern) 1
 R45 (Houston) 1
 (Abbundi) 1
 E23 (Christianson) 1
 E431 9
 E432 3